

OPERATING MANUAL

Autoplus Auto Series | Docking

Congratulations on your purchase of the **MedKlinn Autoplus Docking!**

Please read the following instructions carefully before using the unit. With a little care, it will provide you with many years of clean, fresh and healthy living spaces.

WARNINGS


1. Do not allow children to play with the device.
2. Do not immerse the device in water, or allow water or any fluids to enter the device.
3. Do not modify, disassemble or repair this device by yourself.
4. Do not attempt to open the device. No repairs/ maintenance are to be carried out by the user. Opening the device or tampering with it in any way will cause the Warranty to become void. If you encounter any problems with the device, please read the Troubleshooting Guide First, and if the problem persists, please contact your nearest authorized MedKlinn Service Centre.
5. Do not wipe the device with benzene or pain thinner.

CAUTIONS DURING OPERATION

1. Do not insert any sharp or pointed object through the Autoplus socket or USB socket. Doing so may cause an electric shock and damage of the device.



DEVICE IDENTIFICATION




① Autoplus socket ② USB socket (output) ③ Grip (removable)

④ Micro USB socket (input) ⑤ LED indicator ⑥ Micro USB connector


⑦ USB connector

OPERATION



1. Insert the Autoplus in the Docking.
2. Insert the micro USB connector into the micro USB socket (input) of the docking station.
3. Insert the USB connector into the USB socket of your vehicle.
4. A blue LED light will appear at the front of the Docking. This indicates that the docking is functioning.

OPERATION



Range of Rotation is 60 degree.

Please ensure the Autoplus is facing out. The Autoplus can be rotated up to suit the configuration of your vehicle. Gently rotate the Autoplus until it reaches the desired position.

Remarks: The USB socket of the docking can be used as a source of power supply for the other devices such as phones, tablets and etc.

MAINTENANCE AND SERVICING

There is no routine or regular maintenance required.

TROUBLESHOOTING GUIDE

1. I have inserted the USB cable into docking station and connect to the vehicle's USB socket, but the LED light is not lit.

First, ensure the vehicle's USB socket is functioning. Then make sure the USB cable is securely inserted into the USB sockets, and that the vehicle's ignition is turned on.

If the LED light is not lit, check if the Autoplus is functioning. If Autoplus is functioning, it means the LED light is damaged. The Docking is still functioning normally.

If the Autoplus is not functioning, use another USB cable and repeat the above steps. If the Autoplus is functioning with another cable, it means your cable has malfunctioned.

If the Autoplus still does not function with another cable, contact your nearest authorized MedKlinn Service Centre.